

myGRIMME

- The GRIMME customer portal
- The customer can create and display all his GRIMME machines clearly arranged
- All machine-specific documents such as operator manual, maintenance instructions and spare parts list can be viewed

Store Loader Control

- Various automatic functions for store hall filling to relieve the user
- SL Control I:
Swivelling range adaptation
- SL Control II:
Swivelling range adaptation and Discharge height adaptation
- SL Control III:
Swivelling range adaptation and discharge height adaptation, filling of an inclined section by pulling in the conveyor belt, filling of a horizontal level by pulling in and lifting the conveyor belt and terrace filling function.

GRIMME

i-systems

Capacity Control

- Hopper floor speed control and throughput depending on crop height in the Receiving Hopper
- Optimal use of storage line capacity
- Without manual adjustment
- Controlled remaining quantity in the bunker as well as a constant crop flow on the PU spiral coils and following conveyors for optimum gentle crop handling
- Stop of the entire line with small residual quantity

Flow Control

- Line control: Start and stop of the entire storage line at the push of a button
- Work relief for the operator
- Increased crop protection
- Also possible with non-GRIMME machines

